



SÔLT

90cm Dual Fuel Freestanding Cooker Quick Start Guide

Tips for Using & Operating Your Freestanding Cooker
Model: GGSUC908S.1



90cm Dual Fuel Freestanding Cooker Getting Started...

Oven Modes Explained



Light: This turns on the two oven cavity lamps.



Bake (Conventional): Heat from both the upper and lower elements is used to prepare your food.



Fan Forced: This uses the central rear heating element and fan to distribute heat evenly.



Fan Bake: This uses the upper and lower elements and fan to distribute heat evenly for multiple dishes at once.



Fan Grill: Fan combined with the upper element and grill element.



Grill: Upper grill heating element.



Full Grill: Powerful upper grilling using both grill elements.



Lower Element: Heat from only the lower element, perfect for a range of pastry dishes.



Defrost: The oven fan circulates the air at room temperature, enabling you to quickly defrost food.

The Control Panel



A Clock/Timer

Use these controls to set a timer, cooking duration, or adjust the clock.

B Mode Selector

Use this knob control to select the type of oven cooking mode.

C Temperature Controls

Use this control to select a temperature between 60°C and Max.

D Cooktop Zone Controls

Use these knobs to control the corresponding indicative burner areas.

Installation

For a complete installation guide, refer to the Installation Instructions in the user manual pages 21–29.

Dimensions

Size (mm): 895W × 595D × 858-918H