




SOLT

90cm Slide-out Rangehood Quick Start Guide


Tips for Using & Operating Your 90cm Slide-out Rangehood
Model: GGSSL900S



90cm Slide-out Rangehood Getting Started...

The Controls

- Off**
This setting will turn the rangehood fan off.
- Low Speed**
This setting adjusts the extraction to the lowest speed. It is suitable for regular cooking, including simmering and cooking without much steam.
- High Speed**
This setting adjusts the extraction to the highest speed. Use this fan setting for heavy smoke or steam to achieve the maximum exhaust efficiency.
- Light**
Press this switch to turn the built-in lamp on and off.



Installation & First Use

Before installing your new Slide-out Rangehood, please ensure you first read all of the safety instructions contained in the provided user manual.

The typical installation method for your rangehood is into a purpose built cupboard or by wall mounting.

Please refer to the dimensions of your rangehood shown in the diagram below.

When positioning the rangehood for installation and use, we advise that the rangehood is mounted at a height of at minimum 650mm above your cooktop for safety and performance reasons.

For a complete installation guide, refer to user manual pages 08-12.

