




SÔLT

43L Beverage Chiller

Quick Start Guide

Tips for Using & Operating Your Beverage Chiller
Model: GGSBC43B



V 1.0 | 0821

43L Beverage Chiller

Getting Started...

Before First Use

Before turning on your beverage chiller for the first time:


- The beverage chiller must be rested for at least 6 hours in its location, before connecting to power and switching on.
- Clean the inner chamber and leave the door open during this 6-hour resting period to allow any residual odours to clear.
- Do not connect beverage chiller to electronic energy saving plug or converter that can convert DC into AC (E.g.: solar energy system, ship grid).

Operation Instructions

After you switch on your beverage chiller for the first time, you can use the Temperature Control knob (Image below) located in the rear of your beverage chiller, to set your preferred temperature.

The temperature options are as follows:

- “Cold” is the warmest setting (approx. 10 °C)
- “Normal” is the typical setting (approx. 5-6 °C)
- “Colder” is the coldest setting (approx. 1 °C).



Reversing the Door

Your beverage chiller is supplied with the door hinged to the right hand side. If you would like to reverse the hinging of your Beverage Chiller door (i.e. hinge it on the left hand side), please follow the steps on Pages 12 & 13 of your User Manual.

Energy Saving Tips

The appliance should be placed in the coolest area of the room, away from heat producing appliances or heating ducts. A suitable insulation board shall be applied if necessary.

Please avoid placement in direct sunlight.

Try to shorten opening time of cooler's door. Regular opening of your Beverage Chiller door may lead to condensation on the glass door, particularly if the external air is humid. This is completely normal with all beverage chillers.