

SÔLT

Beverage Chiller 44L Capacity Quick Start Guide

Tips for Using & Operating Your Beverage Chiller Model: GGSBC44B





Beverage Chiller 44L Capacity

Getting Started...

First Time Use

Before connecting the beverage chiller to the power source, let it stand upright for approximately 2 hours. This will allow any refrigerant gases that may have been disturbed during the transportation process to settle and reduce the possibility of a malfunction in the cooling system.

Clean the inner chamber and leave the door open during this 2 hour resting period to allow any residual odours to clear.

For more information on Getting Started, refer to the user manual page 11.


Positioning the shelves

Position the shelf supports inside the cavity on the sides at your desired levels. You can place the shelf firmly on the supports and begin to load your contents.

Dimensions

Size (mm): 470W × 440D × 495H

The Controls



After you switch on your beverage chiller for the first time, use the Temperate Control knob, located in the rear of your beverage chiller cavity, to set your preferred temperature.

"Cold" is the warmest setting.

"Colder" is the coldest setting".

"Off" will stop the appliance from operating.

The beverage chiller temperature range is 1° C – 10° C (33° F – 50° F).

Temperature Range

1-10° C