




SÖLT

# 266L Top Mount Fridge

## Quick Start Guide

**Tips for Using & Operating Your New Fridge**  
Model: GGSTM266B



# 266L Top Mount Fridge


## Getting Started...

### Installation Tips

Please refer to pages 9–13 of the user manual for detailed installation instructions.

Before connecting the fridge to the power source, let it stand upright for a minimum of 2 hours.

### The Thermostat Controls



Setting Button (\*)

Temperature Levels (1, 2, 3, 4, 5)

The LED indicators will display the set refrigeration setting. Pressing the setting button will alternate one temperature setting at a time. Your fridge comes set to a medium temperature setting by default.

### Product Details


Size (W,D,H): 545 × 610 × 1657mm

Weight (Gross/Net): 51kg / 47kg

Energy Rating: 3 Stars

Warranty: 2 Years

### Your Fridge



1. Freezer Glass Shelf (x 1)
2. LED Interior Lamp
3. Damper Adjusting Slider
4. Temperature Control Panel
5. Refrigerator Glass Shelf (x 4)
6. Fruit and Vegetable Crisper Drawer
7. Freezer Door Compartment (x 2)
8. Refrigerator Door Compartment (x 4)
9. Adjustable Foot

### Get in touch

Need help? Contact our friendly support team via the contact details below.

Phone: 1300 11 4357

Email: [support@residentiagroup.com.au](mailto:support@residentiagroup.com.au)