MODEL GGSTF1033TB

V 1.4 | 0422



User Manual

Tower Fan



Welcome Congratulations on purchasing your new Tower Fan! The Sôlt brand is proudly distributed within Australia by Residentia Group Pty Ltd.

Residentia Group

Head Office. 165 Barkly Ave Burnley Victoria 3121 Australia – ACN. 600 546 656 – Online. residentia.group

Sôlt

Online. www.solt.house

Instagram. /solt.house

Facebook. /solt.appliances Please refer to the warranty card at the rear of this manual for information regarding your product's parts and labour warranty, or visit us online at www.residentia.group

At Residentia Group, we are customer obsessed and our Support Team are there to ensure you get the most out of your appliance. Should you want to learn more about your Tower Fan features, and importantly taking care of your appliance when cleaning, our Support Team are here to help.

You can use our online Support Centre at anytime by visiting http://support.residentiagroup.com.au, or you can contact us via calling us on 1300 11 HELP (4357).

It is important that you read through the following use and care manual thoroughly to familiarise yourself with the installation and operation requirements of your appliance to ensure optimum performance.

Again, thank you for choosing an Sôlt appliance and we look forward to being of service to you.

Kind Regards, The Residentia Team

Contents

2 Welcome

- **4** General Instructions
- **5** Your Tower Fan
- **6** Assembly Instructions
- **7** Operating Instructions
- 8 Technical Specifications
- **9** Purchase Details
- **10** Warranty Information

Customer Care

Sôlt recommends the use of original spare parts. When contacting our customer service team, please ensure that you have the following information at hand (which can be found on your appliances' rating plate).

Model Number

- Serial Number

T. 1300 11 4357 | E. support@residentiagroup.com.au

General Instructions

CONDITIONS OF USE

- Indoor use only.
- This appliance is intended to be used in household and other residential type of environments.

SAFETY INSTRUCTIONS

- Before using the appliance, carefully read the instructions in this manual.
- The manufacturer is not responsible if an incorrect installation and use causes injuries and damages.
- Always keep the instructions with your appliance for future reference.

WARNING: To prevent any damages to your and others' life or property, you have to follow the safety notes.

CHILDREN & VULNERABLE PEOPLE SAFETY

WARNING: Risk of suffocation, injury or permanent disability.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep all packaging away from children.

INSTRUCTIONS FOR SAFE OPERATION

- Never insert fingers, pencils, or any other foreign
- object through the grille when fan is running.Disconnect fan when moving from one location
- to another.
 Be sure fan is on a stable surface when operating
- to avoid overturning.
- DO NOT use the fan near a window, rain may create
- electrical hazard.
- Household use only.

INSTALLATION

- Remove all the packaging.
- Do not assemble or use a damaged appliance.
- After you have assembled the Tower Fan, do not take off the rotor blade guard anymore.

ELECTRICAL CONNECTION

WARNING: Caution, risk of fire and electrical shock!

- If the supply cord is damaged, it must be replaced by manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- To ensure your safety, power plug must be inserted into an earthed three-pole socket. Check carefully and make sure that your socket is properly and reliably earthed.
- To protect against the risk of electrical shock, do not immerse the unit, cord or plug in water or other liquid.
- When the appliance is not in use and before cleaning, unplug the appliance from the outlet.

MAINTENANCE & CLEANING

WARNING: Risk of injury or damage to the appliance.

- Prior cleaning unplug the fan.
- Do not disassemble or open the rotor guard to clean the rotor blades.
- When the appliance is not in use and before cleaning, unplug the appliance from the outlet.
 Clean the appliance with a moist soft cloth.
- Clean the appliance with a moist soft cloth. Only use mild soaps and thoroughly remove soap film with a dry cloth.
- Do not use abrasive products, abrasive cleaning pads, solvents or metal objects.
- Do not use gasoline, thinner or similar products as a cleaner.
- Do not allow water or any other liquid into the motor housing or interior parts.

WARNING

Only authorised technicians can carry out repairs.

Note: Your appliance requires little maintenance. If you are experiencing issues, do not try to resolve the issue or fault by yourself. If you appliance requires maintenance:


- Power off the appliance using the Power button.
- Switch off the appliance at the power outlet and remove the plug.
- Contact our customer service team.

PRODUCT DISPOSAL

- Disconnect the appliance from the mains supply.
- Cut off the mains cable and discard it.

Your Tower Fan

PRODUCT OVERVIEW



Control Panel
 Tower Fan Body
 Rear Base
 Front Base
 Plastic Nut
 Power Cord
 Included by not shown:


 Remote Control

Note: The images in this user manual are for explanatory purposes only. Your Tower Fan may appear slightly different.

Assembly Instructions

STEP 1

Take out the Tower Fan Body and assembly parts from the box. Join the Front Base onto Rear Base by connecting them together.



STEP 2 Unlock the Plastic Nut from the fan body.



STEP 3

Pass the Power Cord through the flute, then insert the Tower Fan Body into the Base.

STEP 4


Fix the Tower Fan Body on the Base with the Plastic Nut from Step 2.



Operating Instructions

CONTROL PANEL

The buttons on the Control Panel body (Power, Speed, Swing, Mode & Timer) are the same functions as the corresponding buttons on the Remote Control.



ப

1. Power Button: This button will power the Tower Fan on and off.

K

2. Speed: When the Tower Fan is powered on, the Fan Speed can be set to 3 different wind speeds + ECO. The selected Speed setting will be displayed on the corresponding indicator light.

3. Swing (Oscillation): After the Tower Fan is powered on, press the Swing Button to select oscillation mode. The Swing indicator light will be displayed.

(M)

4. Mode: Press this button to toggle between one of three mode settings:



Normal: The wind remains a constant flow.

Breeze: Variable wind patterns that simulates the wind outdoors.

- Night Mode: Ideal for a cool, long night's sleep. Choose between the 3 speed settings:
 Low, constant wind speed.
 - Low, constant wind speed
 - 2. Medium, constant wind speed which will gradually slow to a low, constant speed.
 - High, constant wind speed which will gradually slow to a low, constant speed.


The selected Mode setting will be displayed on the corresponding indicator light.

the Operating the Remote Control

REMOTE CONTROL

- Point the Remote Control at the receiver on the Tower Fan body and press the desired function button.
- The Remote Control will operate at distances of up to five meters and at an angle of 30 degrees.
- The batteries must be removed from the Remote Control before it is scrapped and that they are disposed of safely.

Note: Only use manganese or alkaline "AAA" batteries. Do not use rechargeable batteries.



Note:

- The images in this user manual are for explanatory purposes only. Your Tower Fan and Remote Control may appear slightly different.
- The middle button (•••) on the Remote Control does not have a set function for your Tower Fan (GGSTF1033TB).

BATTERY WARNING

- Do not dispose of batteries in fire. Batteries may explode or leak.
- · Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

5. Timer: Press the Timer Button to program the Fan to power off automatically between 1–15hrs.

Technical Specifications

Below outlines the technical specifications for your Tower Fan.

Model	GGSTF1033TB			
Dimensions (W \times D \times H mm)	300 × 300 × 1013 mm			
Net Weight	3.7kg			
Rated Power	45W			
Power Supply	220-240V~, 50Hz			

Purchase Details

For future reference, please record the following information which can be found on the rating plate and the date of purchase which can be found on your sales invoice.

STORE DETAILS

STORE NAME	I		
ADDRESS	1		
TELEPHONE	1		
PURCHASE DATE	1	 	
PRODUCT DETAILS		 	
MODEL NO.	1		
SERIAL NO.*	1		

Attach your receipt to this page

Warranty Information

WARRANTY TERMS & CONDITIONS TOWER FAN

This document sets out the terms and conditions of the product warranties for Residentia Group Appliances. It is an important document. Please keep it with your proof of purchase documents in a safe place for future reference should you require service for your Appliance.

IN THIS WARRANTY 1.

- 'acceptable quality' as referred to in clause 10 of this warranty has the same meaning (a) referred to in the ACL;
- (b) 'ACL' means Trade Practices Amendment (Australian Consumer Law) Act (No.2) 2010;
- 'Appliance' means any Residentia Group (c) product purchased by you accompanied by this document:
- (d) 'ASR' means Residentia Group authorised service representative;
- (e) 'Residentia Group' means Residentia Group Pty Ltd of 165 Barkly Ave, Burnley VIC 3121, AČN 600 546 656 in respect of Appliances purchased in Australia;
- 'major failure' as referred to in clause 10 (f) of this warranty has the same meaning referred to in the ACL and includes a situation when an Appliance cannot be repaired or it is uneconomic for Residentia Group, at its discretion, to repair an Appliance during the Warranty Period; 'Warranty Period' means:
- (q)
 - (i) where the Appliance is used for personal, domestic or household use (i.e. normal single family use) as set out in the instruction manual, the Appliance is warranted against manufacturing defects for 24 months, following the date of original purchase of the Appliance;
- (h) 'you' means the purchaser of the Appliance not having purchased the Appliance for re-sale, and 'your' has a corresponding meanina.
- 2. This warranty only applies to Appliances purchased and used in Australia and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia.
- 3. During the Warranty Period Residentia Group or its ASR will, at no extra charge if your Appliance is readily accessible for service, without special equipment and subject to these terms and conditions, repair or replace any parts which it considers to be defective. Residentia Group or its ASR may use remanufactured parts to repair your Appliance. You agree that any replaced Appliances or parts become the property of Residentia Group. This warranty does not apply to light globes, batteries, filters or similar perishable parts.
- Parts and Appliances not supplied by 4. Residentia Group are not covered by this warranty.

- 5. You will bear the cost of transportation, travel and delivery of the Appliance to and from Residentia Group or its ASR. If you reside outside of the service area, you will bear the cost of:
- (a) (b) travel of an authorised representative; transportation and delivery of the Appliance to and from Residentia Group or its ASR, in all instances, unless the Appliance is transported by Residentia Group or its ASR. the Appliance is transported at the owner's cost and risk while in transit to and from Residentia Group or its ASR
- 6 Proof of purchase is required before you can make a claim under this warranty
- 7 You may not make a claim under this warranty unless the defect claimed is due to faulty or defective parts or workmanship. Residentia Group is not liable in the following situations (which are not exhaustive): (a)
 - the Appliance is damaged by:
 - accident (i) (ii)
 - misuse or abuse, including failure to properly maintain or service
 - (iii) normal wear and tear
 - (iv) power surges, electrical storm damage or incorrect power supply
 - incomplete or improper installation (v) (ví) incorrect, improper or inappropriate
 - operation (vii) insect or vermin infestation
 - (viii) failure to comply with any additional instructions supplied with the Appliance;
- (b) the Appliance is modified without authority
- from Residentia Group in writing; (c) the Appliance's serial number or warranty
- seal has been removed or defaced;
- (d) the Appliance was serviced or repaired by anyone other than Residentia Group, an authorised repairer or ASR.
- 8. This warranty, the contract to which it relates and the relationship between you and Residentia Group are governed by the law applicable where the Appliance was purchased.
- 9. To the extent permitted by law, Residentia Group excludes all warranties and liabilities (other than as contained in this document) including liability for any loss or damage whether direct or indirect arising from your purchase, use or non use of the Appliance.

- 10. For Appliances and services provided by Residentia Group in Australia, the Appliances come with a guarantee by Residentia Group that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the Appliance repaired or replaced if the Appliance fails to be of acceptable quality and the failure does not amount to a major failure. The benefits to you given by this warranty are in addition to your other rights and remedies under a law in relation to the Appliances or services to which the warranty relates
- 11. At all times during the Warranty Period, Residentia Group shall, at its discretion, determine whether repair, replacement or refund will apply if an Appliance has a valid warranty claim applicable to it.
- 12. Missing parts are not covered by warranty. Residentia Group reserves the right to assess each request for missing parts in a case by case basis. Any parts that are not reported missing in the first week after purchase will not provide free of charge.
- 13. To enquire about claiming under this warranty, please follow these steps:
- (a) carefully check the operating instructions, user manual and the terms of this warranty;
- have the model and serial number (b) of the Appliance available;
- (c) have the proof of purchase (e.g. an invoice) available;
- (d) telephone the numbers shown below.
- 14 You accept that if you make a warranty claim, Residentia Group and its ASR may exchange information in relation to you to enable Residentia Group to meet its obligations under this warranty.

IMPORTANT

Before calling for service, please ensure that the steps in point 13 have been followed.

Telephone contacts

- Service: Please call 1300 11 HELP (4357
- Spare Parts: Please call 1300 11 SPARE (7727)

The Australian Consumer Law requires the inclusion of the following statement with this warranty:

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure and the failure does not amount to a major failure.

An initiative by Residentia Group



T. 1300 11 4357 E. support@residentiagroup.com.au

www.solt.house



